

# Clutch Desk Assembly Instructions - Questions or problems? Call 1-877-857-9609 Mon-Fri. | 9:00am - 5:00pm PST.



Please note: if you have limited space you can start at section B, assemble the subframe first, then assemble the desk top last.

### A

Part	Image	Qty
① Desktop		2
② Metal Plate		1
③ Dowel		3
④ Bolt		4
⑤ Screw		12

Fig. 1

Step 1.  
Place desktop (1) pieces upside down on a padded surface.

Step 2.  
Insert dowels (3) as shown in Fig. 1 and slide the two pieces together.

Step 3.  
Attach the metal plate (2) with bolts (4).

### B

Part	Image	Qty
① Subframe		2
② Connector		2
③ Bolt		8
④ Spacer		1

Fig. 2

Step 4.  
Insert connector (2) between subframe pieces as shown in Fig. 2. Use spacer (4) to help line up the holes then attach with bolts (3).

### C

Part	Image	Qty
① Leg		2
② Leg base		2
③ Levelling feet		4
④ Bolt		4
⑤ L-Bracket		2
⑥ Bolt		4
⑦ Bolt		8

Fig. 3

Step 6.  
Insert levelling feet. Screw all the way in and adjust as necessary once the desk is in place.

Step 7.  
Insert 2 bolts (6) through bottom of leg base (2) and tighten firmly into leg (1).

Fig. 4

Step 8.  
Insert bolts (4) through the subframe and into the top of the leg as shown in Fig. 4.

Fig. 5

Step 9.  
Carefully place the subframe and legs upside down on desk top and insert the 12 screws (A5).

Step 10.  
Attach L-Bracket (C5) with bolt & washer (C7). The washer should be placed on the bolt first and then inserted. Washer should be visible, i.e. - between the head of the bolt and the bracket.

Step 11.  
Gently set desk right side up, adjust the levelling feet as required and put the desk top mouse pad in place.

Fig. 6

**Note:** use the spacer provided to help align the holes. The spacer itself does not attach in any way.